

HOW TO SPECIFY

CENTRO TRAC SYSTEM WITH REMOTE POWER

STEP 1

- a. Start with the Centro Trac Type
- b. Determine the number of RUNs and the length of each RUN. If the runs are over 8', a Connector is required.
- c. Determine Centro System Mounting type



Example:
8' Centro Trac Aluminum

Centro Ceiling Anchor - Stem, Aluminum

STEP 2

- a. Pick a Spot to mount to the Centro Trac
- b. Determine Quantity of Spots for each Run
- c. Determine the total for Centro Trac, Mounting, Connectors, Power Feeds and End Caps to make a complete system



Example:
13 on Two Runs & 8 on Two Runs - 12VAC
LED MR-16 Claro Spot with Centro Trac
Connector, Aluminum

16 - Centro Ceiling Anchor - Stem,
Aluminum



8 - 8' Centro Trac to make four 16' Runs,
Aluminum



4 - Centro Power Canopy, Aluminum



4 - Centro Coupler, Aluminum



8 - Centro End Cap, Black

STEP 3

Pick an LED MR-16 lamp





Example:
42 - 7.5W (Max) Wattage Sora (or equal
by others)

STEP 4

- a. Determine Zoning. i.e. the number of Runs to be controlled together. There may be one or many Zones, with the same or different quantity of Runs in each Zone.
- b. Pick the required wattage Power Supply based on the number of Spots per Zone.

See diagrams on the next page.



NOTES:

- Refer to the Centro Trac specification sheet for System Mounting options.
- Refer to Spot Specification Sheets for max wattage rating for Soraa LED lamps.
- 12VAC or 24VDC Spots & Power Supplies can be used with Centro Trac (must be separate runs).
- Max 300W per circuit.