

HOW TO SPECIFY

WALL MOUNT CANTILEVER MONOPOINT SYSTEM WITH REMOTE POWER

STEP 1

- a. Start with the Cantilever Monopoint
- b. Determine project quantity



Example:
Quantity: 8 Cantilever Monopoints

STEP 2

- Pick a Spot to mount to the Monopoint
(MR-16 -12VAC or Dedicated LED -24VDC)



Example:
8 - 12VAC LED MR-16 Claro Spots

STEP 3


- Pick an LED MR-16 lamp



Example:
8 - 7.5W (Max) Wattage Sora (or equal by others)

STEP 4

- a. Determine Zoning & Power Supply(s). i.e. the number of Monopoints to be controlled together. There may be one or many Zones, with the same or different quantity of Monopoints in each Zone.
- b. Pick the required wattage Power Supply based on the number of Spots per Zone.



NOTES:

- Refer to Tegan's IP-20 Monopoint Power Supply Spec Sheets for the number of Monopoint/Lamp/Spots to use with each Power Supply Wattage based on the Zoning.
- 12VAC or 24VDC Spots & Power Supplies can be used with Monopoints.
- Refer to Spot Specification Sheets for max wattage rating for Sora LED lamps.
- Max 300W per circuit.